

BRYSTON

14B-SST
POWER AMPLIFIER
OWNER'S MANUAL

UPDATED 2006-10-26

Table of Contents

General Introduction	Page 1
Description	
Installation and Ventilation	
Rear Panel Input Settings/Connections	Page 2
Setting Input Selector Switch	
Balance Input Connector Configuration	
Setting Input Sensitivity	
Output Binding Posts	Page 3
Power Control Panel	Page 4
Master Circuit -Breaker	
AC Power Input	
Local/Auto Switch	
Front Panel Description	Page 5
LED Indicator (Power-up Sequence)	
LED Indicator (Operating Conditions)	
Typical Performance Graphs	Page 6-7
External Dimensions	Page 8
Technical Specifications	Page 9
Important Safety Instructions & Warranty Information	Back Cover

Introduction

Thank you for choosing the **14B-SST Stereo Power Amplifier**.

Bryston welcomes any suggestions you may have, or comments regarding the operation of your amplifier. We consider you, our customer, to be Bryston's most important resource, and your opinion is very much appreciated.

Description 14B-SST

The **14B-SST** is a dual channel 600 Watt audio power amplifier. The 14B SST can accept a balanced (3-pin XLR connector) or single ended input (RCA or phono connector) and can be set to a gain of 29dB (sensitivity = 1V) or 23dB (sensitivity = 2V). The 14B-SST includes 'soft start' power control circuitry to eliminate high inrush currents when A/C power is applied. The power up or turn-on of the 14B-SST may be activated by a remote control voltage 4v to 12v ac or dc.

Warranty (see back page for details)
Shipping Box & Packing Material

Please keep the original shipping box and all packing material. This will ensure the amplifier is protected in future transport. In the unlikely event you have a problem and must return it for service you must use the proper packing material. Ship the amplifier only in the original packing material, as the unit is not insurable by carriers otherwise.

Installation (see rack mounting section if applicable)

Ventilation. The most important installation consideration is ventilation. The 14B-SST amplifier is convection cooled. Unrestricted air-flow across the 14B-SST heat sinks is a must. For this reason do not install anything directly above it. Allow 3.5' (2u) to 5" (3u) inches of space above and to the sides of this amplifier. Do not install directly above other heat generating equipment. Should your installation conditions be constricted, then additional forced air-cooling may be necessary. Bryston can provide an optional fan package if required. Thermal shut down during operation indicates insufficient air flow, and a remedy must be found for cooling the amplifier. Provide a minimum 6" space to the rear of the amplifier for ventilation and dressing cables to and from the amplifier.

Never operate the amplifier in a vertical position.

Wiring the 14B-SST amplifier (also see rear panel description)

Speaker wires should be as short as practical. Use quality wire, and if runs are more than 3 meters use at least 12 gage wire. The speaker binding posts will accept wire up to 3 gage in size. Bryston offers speaker cables and amp interconnects for your application. Check our website under products/cables (www.bryston.ca) for more information.

A/C power

Before plugging in the power cord be sure your 14B-SST amplifier is specified for the **correct AC voltage** for your locality. The voltage is listed on the label found at the upper right of the rear panel. The circuit feeding the 14B-SST should be sufficient so as not to cause the circuit breaker to trip (15 amp min.). Note: the 14B-SST when delivering maximum power into a 4 ohm load, will consume all the available power in a normal household circuit, therefore a dedicated electrical circuit may be necessary with this situation. Never lift the safety ground to the amplifier nor remove the ground pin from the plug.

Rear Panel Input / Output Connections




Figure 1

1. Input Select Switch.

The INPUT SELECT switch gives the user the option of switching between either balanced input or single ended input.

2. Input Sensitivity Selection.

This switch changes the gain of the amplifier.

- The 1v setting has a gain of 29dB
- The 2v setting has a gain of 23dB

The optimum gain setting will depend upon the source pre-amp operating level, and or personal preference.

Use the 2v setting with any systems where the volume control rotation is limited to the bottom half of the control or less.

3. Balanced Input connector. (input imp 58K each leg)

This input connector accepts standard 'XLR' or 1/4" Phone jack (Tip-Ring-Sleeve) .

Use quality, 100% shielded cables with *gold plated* connectors.

4. Single Ended Input. (Un-balanced input) (Imp. 50K)

This input connector accepts standard 'RCA' or 'Phono' connectors.

Use quality, 100% shielded cables with *gold plated* connectors.

Balanced input Vs Single ended input:

The balanced input requires a balanced pre-amp source. Balanced systems provide noise rejection from external electrical interference, so cable length can be very long (50m or longer).

The single ended or unbalanced input is provided for pre-amps without balanced output. Single-ended cables should be kept to 20' (7m) or less. In general never use longer cables than necessary, never coil excess cable length, and keep signal wires away from AC power or speaker cables.

5. Level Control. (Pro models only)

The level control will attenuate the input signal level from 0dB through -14dB.

6. Output binding posts.



The **RED** binding post is the ***in-phase amplifier output***. Connect to this post the (+) terminal on the loudspeaker. The **BLUE** binding post is the ***inverted-phase amplifier output***. Connect to this post the (-) terminal on the loudspeaker.

Note: ***At no time should either output be connected to a ground, or chassis***. Failure of the amplifier may result. Never connect either output in parallel with another amplifier.

The *minimum* recommended loudspeaker load is **4 ohms**.

The Output binding posts provide three different interconnect options. Combinations may be used when bi-wiring. See figure 2 below. Cables should be kept as short as practical and should never be terminated with connectors that may become confused for AC power connectors. Cables should be dressed away from input and power cables.

- *Banana plugs* offer a quick disconnect option. Before inserting a banana plug into the binding post be sure to tighten the post nut to avoid rattling and to provide full insertion of the banana plug. Gold plated locking banana plugs are available from Bryston.
- *Spade lugs* provide high contact area and secure fastening. Lugs should be gold plated. See diagram for details. Post diameter is 5/16" (8mm), lug width 5/8" (16 mm). Gold plated spade lugs are available from Bryston.
- *Stripped bare wire* up to 3 gage can be inserted through the hole in the binding post and held in place by tightening the post knob. Additional tightening pressure can be achieved using a **coin** in the slots of the knob. Do not over tighten or the binding post may become damaged. Note that copper wire is malleable and may require further tightening after the initial installation.



Power Control

(refer to figure 1 on page 2)

7. Master circuit - breaker.

The 14B-SST amplifier uses a magnetic-trip circuit breaker to protect the amplifier.

This switch should be 'OFF' during installation. When switched 'OFF'

All A/C power is removed from the amplifier, including standby power.

The circuit breaker is not the power switch and should be switched to and left 'ON' after the installation is complete. Use the 14B-sst front panel power switch or an external control voltage to Power-up or Power-down the amplifier.

Should the breaker trip, lower or remove the amplifier input signal (also see section 9 below). Switch the breaker to the 'ON' position. Then power the unit up normally.

The circuit breaker must be 'ON' at all times for the 14B-SST amplifier to operate.

8. AC power input.

On the rear panel is provided a high current plug for the power cord receptacle. Check that the voltage rating on the label (item 12 in figure 1, page 2) conforms with your locality. With the circuit breaker 'OFF' insert the power cord into the 14B-SST amplifier, then plug the other end to an appropriate A/C power outlet. Switch the circuit breaker to on and observe the LED labeled "Line Voltage Status Indicator".

9. LINE VOLTAGE STATUS INDICATOR

This LED will be on anytime the amplifier is plugged into a source of electrical power. Normally the LED will be green, and it must be green for the amplifier to power on.

Should the amplifier not power on, and the LED is flashing, remove the power cord from the rear of the amplifier and wait a few seconds then plug the power cord back in.

Should the LED be red, a condition exists preventing the amplifier from powering up.

Reasons – the applied electrical power is outside the operating range – 120v unit connected to 230v – Check the electrical ratings label on the rear panel to see if the voltage is correct for your location. Otherwise consult your dealer or call the factory.

10 & 11: External control voltage power up (Local/External switch & Interface Connector)

• To power-up the SST amplifier using an external control voltage:

- 1) Supply a 4v to 12v A/C or DC control voltage to the 'IN' terminals of connector (10).
- 2) Use paired wire of 22 to 18 gage sufficient in length between the source device and the SST amplifier.
- 3) Set slide switch (item 11 in figure 1, page 2) to "External". The amplifier will now power-up only when the control voltage is present (on).


Immediately following power up, the control voltage will appear at the 'OUT' terminals of the interface connector (item 10 on figure 1, page 2, also see below) for the control of other equipment. The removal of the control voltage (0v) causes the amplifier to turn 'off' and the control voltage at the 'OUT' terminals is interrupted.


• In the "Local" setting:

The 14B-SST amplifier will ignore the control voltage, and power up only by using the front panel 'SST POWER' switch, or as in section 3 above. If a control voltage is present at the 'IN' terminals it will still be available at the 'OUT' terminals after the power-up sequence.

Note:

The 'OUT' terminals are connected to the 'IN' terminals once the 14B-SST amplifier has powered-up. The control current is determined by the **source** equipment. The carrying current of the 'OUT' relay is 2 amps. The 14B-SST control circuitry itself draws less than 2 mA from the control current when operating.





FRONT PANEL (refer to illustration above)

13. '14B-SST' power switch

The front panel label '14B-SST', is a push on push off switch used to apply or remove AC line power to the soft start circuitry. (Note: the rear circuit breaker must be on for the amplifier to power-up)

14. LED Indicators

The 14B-SST has an LED indicator to monitor the following conditions:

- UNLIT - indicates the amplifier is turned off.
- RED - indicates the amplifier is muted (in a power-up sequence)
- GREEN - indicates the amplifier operation is normal.
- FLASHING RED - indicates the amplifier clipping.
- ORANGE - indicates channel thermal shutdown.

Power up sequence

After pushing the 'SST POWER' switch, the LED will turn from unlit to red (mute). When the power supply has stabilized the amplifier will come out of mute and the LED will change to green (normal operation).

Unlit LED (power off)

The 14B-SST LED when unlit indicates no A/C mains power is present and the amplifier probably needs only to be powered on or the rear panel circuit breaker is switched off. Should the amplifier not power on when the power switch is pushed see the installation instructions.

Clipping (flashing red)

Clipping occurs when the channel output level no longer can follow the level increase at the input (Over-driven input condition). When the 14B-SST is driven into clipping the LED will change from green to red then back to green when the level is reduced (Flashing Red). Momentary clipping can be tolerated, however it indicates that maximum un-distorted power has been surpassed and potential speaker damage may result if overload conditions persist. Any amplifier that is constantly operated into clipping indicates a more powerful amplifier is needed for that application.


Thermal Shutdown (orange)

The 14B-SST has thermal shutdown circuitry to prevent damage due to overheating.


Should thermal shutdown occur, the amplifier will mute, and the LED will turn orange indicating this condition. When the amplifier has cooled to a safe operating condition the 14B-SST will return to normal operation.

Persistent Thermal shutdown indicates steps need to be taken to increase airflow across the heat sink. (Also see installation section on ventilation).


Typical Band-pass Noise




Typical THD+N Sweep




Typical THD+N Harmonic Content




Typical IMD Sweep




Typical Frequency Response 14B-SST



Typical Phase Response



Damping Factor



Technical Specifications

Power Output

600 watts per channel into 8 ohms
900 watts per channel into 4 ohms

Gain Select and Sensitivity

29dB - 2.5V_{in} = 600W @ 8 Ohms - (Unbalanced position)
29dB - 2.5V_{in} = 600W @ 8 Ohms - (Balanced +6db position)
23dB - 5.0V_{in} = 600W @ 8 Ohms - (Balanced Reg position)

Input Impedance

50K ohms single ended
58K ohms each leg, balanced

Distortion IM or THD+noise

< 0.005% 20Hz to 20kHz at 600 watts into 8 Ω
< 0.007% 20Hz to 20kHz at 900 watts into 4 Ω

Noise Measured with input shorted - 20Hz to 20kHz.
>110dB below rated output 29dB gain (- 75dBu)
>113dB below rated output 23dB gain (- 78dBu)

Slew Rate > 60 volts per microsecond

Power Bandwidth < 1 Hz to over 100 kHz

Damping Factor Over 300 at 20 Hz, ref. 8 ohms

Dimensions - L x H x D

19" version with handles:
48.3 x 20.5 x 52.1cm (19" x 8.05" x 20.525")
See page 8 for more details

Weight: approx. 36.4kg - 80 lbs

Power Consumption & Heat Load

At Idle -	215 Watts
Max. Heat Dissipation -	733 Btu/Hr.
Output @ 600W @ 8 ohms -	1284 Watts
Max. Heat Dissipation 8 ohms -	2333 Btu/Hr.
Output @ 900W @ 4 ohms -	1980 Watts
Max. Heat Dissipation 4 ohms -	3684 Btu/Hr.

IMPORTANT SAFETY INSTRUCTIONS



The lightning flash with arrowhead symbol within an equilateral triangle, is intended to alert the user to the presence of un-insulated “dangerous voltage “ within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer’s instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.



WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE.

DO NOT EXPOSE THIS EQUIPMENT TO DRIPPING OR SPLASHING AND ENSURE THAT NO OBJECTS FILLED WITH LIQUIDS, SUCH AS VASES, ARE PLACED ON THE EQUIPMENT.

TO COMPLETELY DISCONNECT THIS EQUIPMENT FROM THE AC MAINS, DISCONNECT THE POWER SUPPLY CORD PLUG FROM THE AC RECEPTACLE.

THE MAINS PLUG OF THE POWER SUPPLY CORD SHALL REMAIN READILY OPERABLE.

BRYSTON LIMITED WARRANTY

Bryston analog audio circuits are warranted to be free from manufacturing defects for twenty (20) years from the original date of manufacture. The warranty includes parts and labour.

Bryston Digital circuits and cables are warranted for five years from the original date of manufacture. The warranty includes parts and labour.

Bryston products having motorized moving parts, excluding motorized volume controls, are warranted for three years from the original date of manufacture. The warranty includes parts and labour.

Bryston will remedy the problem by repair or replacement, as we deem necessary, to restore the product to full performance. Bryston will pay shipping costs one way (usually the return portion) during the first three years of warranty coverage.

In the event of a defect or malfunction, contact Bryston’s repair centers for return authorization. Products must be returned using original packaging material only. Packing material may be purchased from Bryston if necessary. This warranty is considered void if the defect, malfunction or failure of the product or any component part was caused by damage (not resulting from a defect or malfunction) or abuse while in the possession of the customer. Tampering by persons other than factory authorized service personnel or failure to fully comply with Bryston operating instructions voids the warranty. This warranty gives you specific legal rights and you may also have other rights which may vary from province to province and country to country.

As of 2006-02-22 Bryston will only warranty Bryston products purchased through authorized Bryston dealers. Bryston products with a date code of 0608 or higher (date code format is “yyww”, where “yy” is the two least significant digits of the year and “ww” is the week of the year) must be accompanied by a copy of the bill-of-sale from a Bryston authorized dealer to qualify for warranty service. The warranty is transferable from the original owner to a subsequent owner as long as a copy of the bill-of-sale from the original authorized Bryston dealer accompanies the re-sale. The copy of the bill of sale to any subsequent owner need ONLY include the Name of the Bryston Authorized Dealer and the Model and Serial number of the Bryston product. The warranty will only be honored in the country of the original purchase unless otherwise pre-authorized by Bryston.

BRYSTON SERVICE in CANADA:

Postal address: **P.O. BOX 2170, Stn. Main
PETERBOROUGH, ONTARIO
CANADA K9J 7Y4**

Courier address: **677 NEAL DRIVE
PETERBOROUGH, ONTARIO
CANADA K9J 6X7**

PHONE: 705-742-5325
FAX: 705-742-0882
E-mail: cdnser@bryston.ca

BRYSTON SERVICE in the USA:

**79 COVENTRY ST., Suite 5
NEWPORT, VERMONT
U.S.A. 05855-2100**

PHONE: 802-334-1201
FAX: 802-334-6658
E-mail: usaser@bryston.ca

BRYSTON SERVICE outside Canada and the USA:

contact your local distributor or

CHECK OUR WEB SITE:
E-MAIL BRYSTON DIRECTLY:
FAX BRYSTON DIRECTLY:
PHONE BRYSTON DIRECTLY:

www.bryston.ca
cdnser@bryston.ca
01-705-742-0882
01-705-742-5325